


Identification of Components



Replacement Parts

A	DYN3915	Dynamite Surface Servo
B	DYN1455	6-cell 1200mAh Ni-MH battery
	DYN4113	2A Peak Charger
	ECX9010	Transmitter
C	ECX9012	ESC/Receiver Unit
D	PRB0313	Propeller
E	PRB0301	Hull: MG17
F	PRB0302	Canopy: MG17
G	PRB0303	Boat Stand: MG17
	PRB0304	Decals: MG17
H	PRB0305	Motor Mount Set
I	PRB0306	Drive Shaft with Propeller: MG17
J	PRB0307	Drain Plug
K	PRB0308	Rudder Mount and Assembly
L	PRB0309	Rudder pushrod set
M	PRB0310	Motor with collet
N	PRB0311	Motor cooling assembly
O	PRB0312	Servo hold down with fasteners
P	PRB0401	Hull: IM17
Q	PRB0402	Canopy: IM17
R	PRB0403	Boat Stand: IM17
	PRB0404	Decals: IM17
S	PRB0405	Drive Shaft with Propeller: IM17
T	PRB4012	Antenna Tube

Optional Parts

DYN1468	7.2V 1600mAh Ni-MH Battery, EC3
DYN1469	7.2V 1750mAh Ni-MH Battery, EC3
PRB0100	Marine grease
PRB0102	Waterproof tape