



Part #	Description	Part #	Description		
	BLH4100	120 S RTF	15	BLH3115	Rotor Head Linkage
	BLH4180	120 S BNF	16	BLH3106	Main gear
1	SPMSH2029L	Linear Long, 35mm lead	17	BLH3709	Landing gear Set
2	SPMSH2030L	Linear Long, 60mm lead	18	BLH3114	Main Blade grips with Hardware and screws
3	BLH4101	Main Control Board	19	BLH3108	Servo Pushrod Set with Ball link (2)
4	BLH4102	Tail Boom Set	20	BLH3112	Main Rotor Hub with Hardware
5	BLH4103	Main Motor	21	BLH3128	Main Shaft Bearing 4 x 7 x 2
6	BLH4104	Main Frame	22	BLH3113	Feathering Spindle w/O-rings and bushings
7	BLH4105	Main Shaft w/hardware	23	BLH3129	Tail Motor
8	BLH4106	Swashplate	24	EFLB5001S25	1S, 500 mAh, 25C LiPo Battery, JST
9	BLH4107	Canopy	25	BLH3121	Canopy Mounting Grommets (8)
10	BLH4108	Tail Fin	26	BLH3125	Tail Motor Protective Sleeve
11	BLH4111	Main Blades w/screws		BLH4109	Screw set: 120 S
12	BLH4112	Battery Frame		EFLRMLP6	MLP6DSM transmitter 6 channel SAFE transmitter (RTF only)
13	BLH3117	Tail Rotor		EFLC1010	1S, 500 mAh USB LiPo Charger, JST
14	BLH3705	Canopy Mounts			