TRAXXAS

TRX6
Chassis Assembly

2576
3x8 BCS

8224

8225

3965
2.5x8 CS

6533

8225

2576
3x8 BCS

8818

2593
3x14 BCS

2.6x6 BCS
(self-tapping)

2577
3x10 BCS

8843

8843

5669

2576
3x8 BCS

2065
2065X opt.

2.6x6 BCS
(self-tapping)

2065
2065X opt.

2576
3x8 BCS

8283
8284
2.6x8 BCS
(self-tapping)

8240X

2.6x6 BCS
(self-tapping)

8819

8819

2577
3x10 BCS

2577
3x10 BCS

2616
3x27 BCS

8218

2550
3x8 CCS

2577
3x10 BCS

2575
3x6 BCS

2575
3x6 BCS

2578
3x12 BCS

8080

3215
2.5x6 CS

8080

2591
3x23 BCS

2578
3x12 BCS

2577
3x10 BCS

2578
3x12 BCS

3931
3x8 FCS

2577
3x10 BCS

3931
3x8 FCS

8223

8820

8835

2551
3x10 CCS

2551
3x10 CCS

8215

2580
3x20 BCS

8215
2.5x18
SCREW PIN

8215

8250

3975R

3215
2.5x6 CS

8250

3215
2.5x6 CS

8828

2578
3x12 BCS

2578
3x12 BCS

2578
3x12 BCS

8829

8240X

2578
3x12 BCS

4859
3x10 FCS

8240X

2075X
2075R opt.

8239

8240X

2577
3x10 BCS

8247
8247X opt.

2575
3x6 BCS

2577
3x10 BCS

8250

8811R
8811X

8327

8327

8327

8327

8226

2580
3x20 BCS

8215
2.5x18
SCREW PIN

8215

2551
3x10 CCS

2580
3x20 BCS

2577
3x10 BCS

8327

To gearbox housing

8828

2577
3x10 BCS

2577
3x10 BCS

2577
3x10 BCS

2577
3x10 BCS

2578
3x12 BCS

2578
3x12 BCS

8834

8835

8830

8830

8830

8830

2579
3x15 BCS

2579
3x15 BCS

2577
3x10 BCS

2577
3x10 BCS

2577
3x10 BCS

To battery tray

8238

8828

8828

3215
2.5x6 CS

2577
3x10 BCS

2578
3x12 BCS

2578
3x12 BCS

8828

8028
2.5x15 CS

8028

2576
3x8 BCS

2578
3x12 BCS

8819

2578
3x12 BCS

2577
3x10 BCS

3025

8218

8080

2576
3x8 BCS

2578
3x12 BCS

8080

2577
3x10 BCS

2577
3x10 BCS

8819

2550
3x8 CCS

2550
3x8 CCS

2616
3x27 BCS

2577
3x10 BCS

8818

2593
3x14 BCS

REV 190912-R05
See Parts List for a complete
listing of optional accessories.

Specifications on this page are subject to change without notice. Every
attempt has been made to ensure the accuracy of this drawing; however,
Traxxas cannot be held responsible for typographical or other errors.

TRX6
Front Assembly

Differential Assembly

8283

5103A
7x14x5 BB

5102A
15x21x4 BB

8281

8282

8279
8279R opt.

2617
2.5x8 BCS

5119A
10x15x4 BB

2617
2.5x8 BCS

8269
8269A opt.
8269G opt.
8269R opt.
8269X opt.

8251
8251A opt.
8251G opt.
8251R opt.
8251X opt.

2591
3x23 BCS

8246

To steering servo horn

8347
4mm NL

8252
8252A opt.
8252G opt.
8252R opt.
8252X opt.

2578
3x12 BCS

2523
2.5x10 CCS

8232

8232
8232A opt.
8232G opt.
8232R opt.
8232X opt.

8246

8232

2578
3x12 BCS

5180A
6x13x5 BB

8232

8279
8279R opt.

8280X
8280 opt.
8280R opt.

8241

8283

8232
8232A opt.
8232G opt.
8232R opt.
8232X opt.

2578
3x12 BCS

8283

8281

8260
8260A opt.
8260G opt.
8260R opt.
8260X opt.

8243

2616
3x27 BCS

8260
8260A opt.
8260G opt.
8260R opt.
8260X opt.

8243

3229
2.5x10 CS

8227

2579
3x15 BCS

8244

8244

2618
2.5x16 CS

2579
3x15 BCS

8227

3229
2.5x10 CS

2616
3x27 BCS

8252
2.5x4 BCS

5120A
12x18x4 BB

8228 (left)
8229 (right)
8060 opt.

8062 opt.

8233

8257
8064 opt.

3229
2.5x10 CS

5116A
5x11x4 BB

8232

5117A
6x12x4 BB

8233

8252
8252A opt.
8252G opt.
8252R opt.
8252X opt.

8269

8255A

5104A
4x10x4 BB

2523
2.5x10 CCS

2579
3x15 BCS

8251
8251A opt.
8251G opt.
8251R opt.
8251X opt.

8258

5180A
6x13x5 BB

3229
2.5x10 CS

8269
8269A opt.
8269G opt.
8269R opt.
8269X opt.

8252
8252A opt.
8252G opt.
8252R opt.
8252X opt.

8347
4mm NL

8251
8251A opt.
8251G opt.
8251R opt.
8251X opt.

8269
8269A opt.
8269G opt.
8269R opt.
8269X opt.

8281

REV 190912-R05
See Parts List for a complete
listing of optional accessories.

Specifications on this page are subject to change without notice. Every attempt has been made to ensure
the accuracy of this drawing; however, Traxxas cannot be held responsible for typographical or other errors.

TRAXXAS

TRX6

Rear Assembly

TRAXXAS

8269
8269A opt.
8269G opt.
8269R opt.
8269X opt.

2582
3x30 BCS

8841

8846

8347
4mm NL

8251
8251A opt.
8251G opt.
8251R opt.
8251X opt.

8832

8832

2618
2.5x16 CS

8253
8253A opt.
8253G opt.
8253R opt.
8253X opt.

2523
2.5x10 CCS

2579
3x15 BCS

8256
8256A opt.
8256G opt.
8256R opt.
8256X opt.

8837

8279
8279R opt.

8847

8260
8260A opt.
8260G opt.
8260R opt.
8260X opt.

5116A
5x11x4 BB

5180A
6x13x5 BB

2579
3x15 BCS

2618
2.5x16 CS

8260
8260A opt.
8260G opt.
8260R opt.
8260X opt.

2616
3x27 BCS

2618
2.5x16 CS

2618
2.5x16 CS

8256
8256A opt.
8256G opt.
8256R opt.
8256X opt.

2523
2.5x10 CCS

8253
8253A opt.
8253G opt.
8253R opt.
8253X opt.

8269
8269A opt.
8269G opt.
8269R opt.
8269X opt.

8836

2523
2.5x10 CCS

5119A
10x15x4 BB

8230 (left)
8231 (right)
8063 opt.

8061 opt.

3229
2.5x10 CS

8251
8251A opt.
8251G opt.
8251R opt.
8251X opt.

8347
4mm NL

8836

3229
2.5x10 CS

5117A
6x12x4 BB

8259
8065 opt.

8831

2616
3x27 BCS

8253
8253A opt.
8253G opt.
8253R opt.
8253X opt.

8255A

8269

5104A
4x10x4 BB

3229
2.5x10 CS

8831

8258

5180A
6x13x5 BB

8251
8251A opt.
8251G opt.
8251R opt.
8251X opt.

8269

8269
8269A opt.
8269G opt.
8269R opt.
8269X opt.

REV 190912-R05
See Parts List for a complete
listing of optional accessories.

Specifications on this page are subject to change without notice. Every attempt has been made to ensure
the accuracy of this drawing; however, Traxxas cannot be held responsible for typographical or other errors.

Shock Assembly

8264
8274 opt.

8262

8260
8260A opt.
8260G opt.
8260R opt.
8260X opt.

8263
8263T opt.

8041
(front)

8043
(intermediate and rear)
8040 opt.
8042 opt.
8044 opt.
8045 opt.

8266
8266A opt.
8266G opt.
8266R opt.
8266X opt.

8264

8262

8264

8264
8274 opt.

8269
8269A opt.
8269G opt.
8269R opt.
8269X opt.

8347
4mm NL

8251
8251A opt.
8251G opt.
8251R opt.
8251X opt.

8253
8253A opt.
8253G opt.
8253R opt.
8253X opt.

8256
8256A opt.
8256G opt.
8256R opt.
8256X opt.

8245

8245

2582
3x30 BCS

8284

8281

8846

2618
2.5x16 CS

2523
2.5x10 CCS

2618
2.5x16 CS

8242

8279
8279R opt.

8279
8279R opt.

5180A
6x13x5 BB

5116A
5x11x4 BB

2618
2.5x16 CS

2618
2.5x16 CS

5116A
5x11x4 BB

5180A
6x13x5 BB

2618
2.5x16 CS

8256
8256A opt.
8256G opt.
8256R opt.
8256X opt.

2523
2.5x10 CCS

2523
2.5x10 CCS

8253
8253A opt.
8253G opt.
8253R opt.
8253X opt.

8269
8269A opt.
8269G opt.
8269R opt.
8269X opt.

8260
8260A opt.
8260G opt.
8260R opt.
8260X opt.

8260
8260A opt.
8260G opt.
8260R opt.
8260X opt.

2616
3x27 BCS

8227

8227

2616
3x27 BCS

5119A
10x15x4 BB

8230 (left)
8231 (right)
8063 opt.

8061 opt.

8259
8065 opt.

8251
8251A opt.
8251G opt.
8251R opt.
8251X opt.

8269
8269A opt.
8269G opt.
8269R opt.
8269X opt.

8347
4mm NL

3229
2.5x10 CS

8245

3229
2.5x10 CS

5117A
6x12x4 BB

8253
8253A opt.
8253G opt.
8253R opt.
8253X opt.

8255A

8269

8258

5104A
4x10x4 BB

3229
2.5x10 CS

8245

5180A
6x13x5 BB

8251
8251A opt.
8251G opt.
8251R opt.
8251X opt.

8269
8269A opt.
8269G opt.
8269R opt.
8269X opt.

8269
8269A opt.
8269G opt.
8269R opt.
8269X opt.

REV 190912-R05
See Parts List for a complete
listing of optional accessories.

Specifications on this page are subject to change without notice. Every attempt has been made to ensure the accuracy of this drawing; however, Traxxas cannot be held responsible for typographical or other errors.

TRX6

Transmission and Transfer Case Gears
Note the orientation of the gears

8293
8293X

8285

8293
8293X

8289

8292
8294

8285
8286

5116A
5x11x4 BB

8286
8285

8286
8285

Transfer Case Gears (top view)

5116A
5x11x4 BB

8286

8285

8285

1985
5x8x0.5 PTW

5116A
5x11x4 BB

1985
5x8x0.5 PTW

8286

Transmission Gears (top view)

8285

5116A
5x11x4 BB

5116A
5x11x4 BB

1985
5x8x0.5 PTW

8293
8293X

8293
8293X

5114A
5x8x2.5 BB

8289

8289

8293
8293X

8294

5115A
5x10x4 BB

1985
5x8x0.5 PTW

5116A
5x11x4 BB

8292

2576
3x8 BCS

3965
2.5x8 CS

8295

3965
2.5x8 CS

8291

5116A
5x11x4 BB

8295

5114A
5x8x2.5 BB

8293
8293X

1985
5x8x0.5 PTW

2576
3x8 BCS

8291

8250
8295

8290

8290
8290A opt.
8290G opt.
8290R opt.
8290X opt.

6747
3x3 GS

1552
3x8 CS

3975R

5116A
5x11x4 BB

5115A
5x10x4 BB

1985
5x8x0.5 PTW

5116A
5x11x4 BB

8291

8293
8293X

8286

1985
5x8x0.5 PTW

8285

8285

8286

8293
8293X

8285

8293
8293X

8292

8293
8293X

8289

5114A
5x8x2.5 BB

8294

8289

8053
8052 opt.

8254

8250
(intermediate)

8295

8250
8295

8289

2577
3x10 BCS

5669

2576
3x8 BCS

2576
3x8 BCS

2065

8240X

3965
2.5x8 CS

8238

8254

2575
3x6 BCS

8250 (front)

8295

8250
8849

8849

8250
8849

8250
8295

8295

2577
3x10 BCS

Front & Intermediate Driveshaft Assembly

8250
(intermediate)

8295

8250 (front)

8250

2575
3x6 BCS

Rear Driveshaft Assembly

8849

8850 (rear)

8295

3215
2.5x6 CS

3215
2.5x6 CS

8850 (rear)

8849

8250
8295

8250
8849

8250
8849

5116A
5x11x4 BB

1985
5x8x0.5 PTW

8292

REV 190912-R05

See Parts List for a complete listing of optional accessories.

Specifications on this page are subject to change without notice. Every attempt has been made to ensure the accuracy of this drawing; however, Traxxas cannot be held responsible for typographical or other errors.

Link Dimensions

FRONT LOWER LINK (QTY. 2)
8275 8276 8274 opt.
8275 8276 8274 opt.
75.78mm
114.78mm

FRONT UPPER LINK (QTY. 1)
8275 8277 8274 opt.
8275 8277 8274 opt.
37.61mm
80.39mm

PANHARD BAR (QTY. 1)
8275 8276 8274 opt.
8275 8278 8274 opt.
37.61mm
77.61mm

INTERMEDIATE LOWER LINK (QTY. 2)
8275 8276 8274 opt.
8275 8276 8274 opt.
96.27mm
135.27mm

INTERMEDIATE UPPER LINK (QTY. 2)
8275 8277 8274 opt.
8275 8277 8274 opt.
84.50mm
139.06mm

REAR LOWER LINK (QTY. 2)
8275 8276 8274 opt.
8275 8276 8274 opt.
69.83mm
108.83mm

REAR UPPER LINK (QTY. 2)
8275 8277 8274 opt.
8275 8277 8274 opt.
50.97mm
93.79mm

STEERING LINK (QTY. 1)
8275 8277 8274 opt.
8275 8277 8274 opt.
34.50mm
77.28mm

DRAG LINK (QTY. 1)
8275 8278 8274 opt.
8275 8278 8274 opt.
92.18mm
133.18mm

TRX6

Modular Assembly

TRAXXAS

ROD ENDS
8275 8276
8275 8277
8275 8278

For standard hollow ball replacement, use part #5349.

2591 3x23 BCS Rear shock

2579 3x15 BCS Rear upper link

2591 3x23 BCS Intermediate shock

2616 3x27 BCS Intermediate upper link

2591 3x23 BCS

2579 3x15 BCS Rear lower link

2579 3x15 BCS Front and intermediate lower link

2591 3x23 BCS

2591 3x23 BCS Front upper link

2591 3x23 BCS Intermediate shock

2591 3x23 BCS Rear shock

2579 3x15 BCS Rear upper and lower link

2616 3x27 BCS Intermediate upper link

2579 3x15 BCS Front and intermediate lower link

2579 3x15 BCS

3965 2.5x8 CS

3965 2.5x8 CS

8874

8875

8875

2579 3x15 BCS Steering servo

REV 190912-R05

See Parts List for a complete listing of optional accessories.

Specifications on this page are subject to change without notice. Every attempt has been made to ensure the accuracy of this drawing; however, Traxxas cannot be held responsible for typographical or other errors.

TRX6

Body Assembly

TRAXXAS

8815X
8815X
6644
1.6x5 BCS
(self-tapping)
8815X
8815X
8815X
8815X
6644
1.6x5 BCS
(self-tapping)
8815X
8815X
8815X
6644
1.6x5 BCS
(self-tapping)
8815X
8815X
6644
1.6x5 BCS
(self-tapping)
8815X
8815X
6644
1.6x5 BCS
(self-tapping)

8822
8822
8822
1548
3x4 GS
8822
8822
1548
3x4 GS

8827

8814X
8814X
6644
1.6x5 BCS
(self-tapping)

8825R
8825X
8825 opt.

8817
8817
8817
8817

8814X
6644
1.6x5 BCS
(self-tapping)
8814X

8813X
7943
2.6x8 BCS
(self-tapping)

8816X
1.6x7 BCS
(self-tapping)
8813X
8813X
8816X

8813X

8813X

8814X
8814X

8827
8827
3229
2.5x10 CS

8827
3229
2.5x10 CS

8817

8816X
8816X
1.6x7 BCS
(self-tapping)

6644
1.6x5 BCS
(self-tapping)
6644
1.6x5 BCS
(self-tapping)
8815X
8815X
6644
1.6x5 BCS
(self-tapping)
8815X
8815X
6644
1.6x5 BCS
(self-tapping)
8815X
8815X

8813X
8813X
8813X
8813X
8813X
7943
2.6x8 BCS
(self-tapping)
8813X

8817
6644
1.6x5 BCS
(self-tapping)

8817
8817
8817

8817
6644
1.6x5 BCS
(self-tapping)

8817
8817

8827

8813X
7943
2.6x8 BCS
(self-tapping)

8822

6644
1.6x5 BCS
(self-tapping)
8815X
8815X
8815X
6644
1.6x5 BCS
(self-tapping)
8815X
8815X
8815X

8813X
7943
2.6x8 BCS
(self-tapping)
8813X

8822
2.6x6 BCS

8813X

8822
2.6x6 BCS
8822
2.6x6 BCS

6644
1.6x5 BCS
(self-tapping)
8815X
8815X

8813X
8813X

8813X
8813X
6644
1.6x5 BCS
(self-tapping)

8813X
8813X

8813X
6644
1.6x5 BCS
(self-tapping)

8815X
8815X

REV 190912-R05

Specifications on this page are subject to change without notice. Every attempt has been made to ensure
the accuracy of this drawing; however, Traxxas cannot be held responsible for typographical or other errors.